



1: Place the 0.5" rubber grommet around the junction of the capillary tube and the evaporator inlet tube. If there is permagum around the tubes, place the grommet over the permagum and tube.

2: Place the 1.0" rubber grommet around evaporator inlet on the first aluminum bend. Grommet should sit on the corner of the bend.