


Instruction Sheet for Basket Hub Replacement Kit

! WARNING	
	<p>Electrical Shock Hazard</p> <p>Disconnect power before servicing. Replace all parts and panels before operating.</p> <p>Failure to do so can result in death or electrical shock.</p>

NOTE: The Basket Hub kit you received contains two (2) Driven Basket Hubs and one (1) Driver Hub. One driven hub is the old style hub and the other is the new style. When installing the Driven Basket Hub be sure you use the correct hub for your particular application.

IMPORTANT: To determine which Driven Basket Hub to use on your washer, compare the surface of your basket base where the hub installs to the base. See *Figure 1*. Then compare the two hubs included in this kit to the defective hub. See *Figure 1*.




Figure 1